



Autoprint Formula Solution Pvt. Ltd.

Alphacare 861 Anilox Cleaner

Washing agent for anilox rollers (aqueous varnish)

February 2022

Product Description & Application

Over time and depending of use the cells in an anilox roller are prone to get filled up by dried ink residue and thus reduce its ink transfer capacity area-wise or entirely.

Hence it is recommended to wash the rollers after use with a specific anilox cleaner to upkeep the rollers in perfect transfer condition.

The formula of this anilox cleaner allows effective removal of hard deposits of **aqueous varnishes**, coatings and inks from all kind of engraved or moulded anilox rollers. It works as well on rubber roller and blankets.

Features & Benefits

- Effectively applicable for anilox rollers/cylinders, coating blankets, rubber rollers in offset and flexo presses;
- Cleans dried aqueous varnishes even hard baked deposits;
- Protecting formula for anilox rollers that enables both, prefect cleaning and long life maintenance;

Use and product instruction

- Spread evenly the cleaner over the surface of the anilox roller;
- Use sufficient amount according the degree of the depositions;
- Treat the surface with an appropriate brush or tissue gently in a circular motion. Leave for dissolving reaction over a period of approximately 10 minutes;
- Remove the residues with a sponge and rinse any remaining with enough water;
- Repeat the process in case the roller cells are severely clogged;

The same treatment can be applied to dissolve and remove aqueous varnish from a coating blanket, gripper or other metal part. **Caution:** For painted surface, test the product for suitability first.

Storage/Handling & Packaging

Storage and handling	<ul style="list-style-type: none"> • Store at moderate temperatures (8 - 40°C). • The use of safety gloves is strongly recommended. • Keep container tightly closed • Keep away from direct sun light
Shelf life	12 month from the date of manufacturing
Packing	5/10/20 litre can/container
Caution	avoid contact with skin and eyes

Contact details

AFOSOL Autoprint Formula Solution Pvt. Ltd.
 Office: No 7, North Huzur Road, Coimbatore 641018
 Support: Phone +91 422 221 2416/+91 422 221 6750
 E-mail: support@afosol.com
 Webpage: www.afosol.com