



Autoprint Formula Solution Pvt. Ltd.

# Alphacare 835 Plate Cleaner

The preservation of plates for later re-use requires proper treatment

February 2022

## Product Description & Application

To preserve plates for reusing require proper treatment. This emulsion is of general purpose for positive and negative offset printing plates. It activates non-image areas and removes dried printing ink gently from aluminum surface. The cleaner works with oil based ink, contains mild solvent, has a high viscosity, is easy to sponge onto plate surface and develops a slight abrasive effect to remove residues and to eliminate scratches.

## Features & Benefits

- For use on conventional, baked and unbaked CtP-plates;
- Slight abrasive effect, hence removes even stubborn ink and gum residues;
- Effective and fast ink removal on all parts of the plate surface;
- Eliminate scratches to a certain extent;
- Activates non- imaged areas and suppresses scumming;
- Easy to sponge onto the plate surface;
- Residual can be removed with water;

## Use and product Instructions

- Jolt the can before use and disperse the liquid to the plate surface with a soft moist tissue;
- Remove the residue with a fresh soft moist tissue and continue printing;
- For plate storage wipe off the ink first and apply gum for conservation;
- Because of the abrasive effect avoid too much pressure whilst wiping;
- Not recommended when using UV-curing inks;

## Storage/Handling & Packaging

Storage and handling	<ul style="list-style-type: none"> <li>• Store at moderate temperatures (8 - 40°C).</li> <li>• The use of safety gloves is recommended.</li> <li>• Keep container tightly closed</li> <li>• Keep away from direct sun light</li> </ul>
Shelf life	12 month from the date of manufacturing
Packing	5/10/20 litre can/container
Caution	avoid contact with skin and eyes

## Contact details

**AFOSOL** Autoprint Formula Solution Pvt. Ltd.  
Office: No 7, North Huzur Road, Coimbatore 641018  
Support: Phone +91 422 221 2416/+91 422 221 6750  
E-mail: [support@afosol.com](mailto:support@afosol.com)  
Webpage: [www.afosol.com](http://www.afosol.com)