



Autoprint Formula Solution Pvt. Ltd.

Alphacare 851 Blanket Cleaner

Apply blanket cleaner and conditioner to remove dried ink residues

February 2022

Purpose & Application

Blanket maintenance is important to ensure perfect image transfer to the substrate. From time-to-time blanket cleaner and conditioner are recommended to remove dried ink residues.

The fluid penetrates deep into the pores of the rubber surface, dissolves dried-up particles and thus rejuvenates the rubber blanket.

Features & Benefits

- Very strong ink dissolving capacity achieved by a blend of solvents;
- Powerful ink remover for manual cleaning;
- Special suitable for cleaning rubber blankets, cylinders and baked-on ink;
- Rejuvenates, reconditions blankets and optimizes image transfer;
- Free of chlorinated compounds;
- Flashpoint > 55 °C;
- Used for preparing new blanket before printing;
- Water washable and dries quickly;
- Applicable for UV-curing and oil-based inks equally;

Use and product Instructions

Remove ink from the blanket by using a wash-up solution, ideally certified by FOGRA and wipe dry. Apply *Alphacare 851 Blanket Cleaner* on a cotton cloth and clean manually the blanket surface.

Continue wiping for 30 to 60 seconds, swap dry after that and wet wash the surface thoroughly with water before starting the print process.

Storage/Handling & Packaging

Storage and handling	<ul style="list-style-type: none"> • Store at moderate temperatures (8 - 40°C). • The use of safety gloves is recommended. • Keep container tightly closed • Keep away from direct sun light
Shelf life	12 month from the date of manufacturing
Packing	5/10/20 litre can/container
Caution	avoid contact with skin and eyes

Contact details

AFOSOL Autoprint Formula Solution Pvt. Ltd.
Office: No 7, North Huzur Road, Coimbatore 641018
Support: Phone +91 422 221 2416/+91 422 221 6750
E-mail: support@afosol.com
Webpage: www.afosol.com